

Island Trunk System

Revised 23 August 2018

The latest Trunk System block diagram includes the most recent additions and changes to the Island Trunk System.

GREEN repeaters are normally left connected together via the trunk so what goes in on one is heard on all.

BLUE repeaters are not permanently connected to the trunk but may be connected at the user's pleasure. Please disconnect after use.

ORANGE repeaters are a backup only and are only to be used on demand in the event that the primary repeater has failed.

Please see our website for the latest Information.

www.islandtrunksystem.org

Thanks from
The Island Trunk Folks

For Emergency Use Only
Permanently Connected
Connect at User's Pleasure
Unserviceable Repair Date Unknown

ISLAND TRUNK SYSTEM

92* ON 93* OFF	→	146.920 Port McNeill
94* ON 95* OFF	→	146.940 Port McNeill
88* ON 89* OFF	→	146.880 Woss Lake
70* ON 71* OFF	→	146.700 Sayward
82* ON 83* OFF	→	146.820 Campbell River
→		443.700 Courtenay 141.3 pl
→		146.880 Tofino 141.3 pl
15* ON 16* OFF	→	147.150 Port Alberni 141.3 pl
43* ON 44* OFF	→	145.430 Nanaimo 141.3 pl
472* ON 473* OFF	→	444.725 Nanaimo 141.3 pl
→		442.600 Chemainus 141.3 pl
→		146.680 Chemainus 141.3 pl