

# Island Trunk System

Revised 20 May 2018

The latest Trunk System block diagram includes the most recent additions and changes to the Island Trunk System.

**GREEN** repeaters are normally left connected together via the trunk so what goes in on one is heard on all.

**BLUE** repeaters are not permanently connected to the trunk but may be connected at the user's pleasure. Please disconnect after use.

**ORANGE** repeaters are a backup only and are only to be used on demand in the event that the primary repeater has failed.

Please see our website for the latest Information.

[www.islandtrunksystem.org](http://www.islandtrunksystem.org)

Thanks from  
The Island Trunk Folks

For Emergency Use Only
Permanently Connected
Connect at User's Pleasure
Unserviceable Repair Date Unknown

## ISLAND TRUNK SYSTEM

92* ON 93* OFF	→	146.920 Port McNeill
94* ON 95* OFF	→	146.940 Port McNeill
88* ON 89* OFF	→	146.880 Woss Lake
70* ON 71* OFF	→	146.700 Sayward
82* ON 83* OFF	→	146.820 Campbell River
→		443.700 Courtenay 141.3 pl
→		146.880 Tofino 141.3 pl
15* ON 16* OFF	→	147.150 Port Alberni 141.3 pl
43* ON 44* OFF	→	145.430 Nanaimo 141.3 pl
472* ON 473* OFF	→	444.725 Nanaimo 141.3 pl
→		442.600 Chemainus 141.3 pl
→		146.680 Chemainus 141.3 pl